



S028 7000 S029 7300 S030 6900 S031 7200 S032 7100 S033 7000 S034 7200 S035 7300 PE 1000



終点
高知市春野

至 高知市神田
至 高知市神田

